

Fujitsu 1st (active) - Serieller Adapter - RS-232

für Celsius J580 - W580; ESPRIMO D738 - D738/E94 - D958 - D958/E94 - P758 - P758/E94 - P958 - P958/E94

| | |
|---------------------|------------------|
| Gruppe | Kabel / Adapter |
| Hersteller | Fujitsu |
| Hersteller Art. Nr. | S26361-F3316-L15 |
| EAN/UPC | 4059595603857 |



Beschreibung

Fujitsu 1st (active) - Serieller Adapter - RS-232 - für Celsius J580, W580; ESPRIMO D738, D738/E94, D958, D958/E94, P758, P758/E94, P958, P958/E94

Hauptmerkmale

| | |
|---------------------|---|
| Produktbeschreibung | Fujitsu 1st (active) - Serieller Adapter - RS-232 |
| Gerätetyp | Serieller Adapter |
| Ports | RS-232 |
| Data Link Protocol | RS-232 |
| Entwickelt für | Celsius J580, W580, W580power, W580power+; ESPRIMO D738, D738/, D738/E94+, D958, D958/, D958/E94+, P758/, P758/E94+, P958/, P958/E94+, P958/power |

Technische Daten © 1WorldSync. Technische Änderungen und Irrtümer vorbehalten.